FOOXX ONE ARRIVAL (RNAV) TAMPA, FLORIDA 🗘 seminole TAMPA APP CON 132.52 269.1 SZW LAKELAND LINDER RGNL ATIS 118.025 MAC DILL AFB ATIS 133.825 270.1 TAMPA INTL ATIS ARR ST. PETERSBURG-CLEARWATER INTL ATIS **VANDENBURG AWOS-3** 121.125 **LEGGT** Expect to cross at FL270 **TABIR** KTPA Landing North: Expect to cross at 13,000'. KTPA and KPIE Landing South: Expect to cross at 13,000' and 250 KIAS. **DARBS** KTPA Landing North and KTPA and KPIE Landing South: Expect to cross at 10,000' HUGMA DADPE Landing All Satellite Airports and VANDENBURG KTPA and KPIE Landing South: Expect radar vectors prior to DADPE WP. TAMPA INTL ST. PETERSBURG-CLEARWATER INTL MAC DILL AFB NOTE: For non-GPS equipped aircraft, LAL must be operational. **BAYZZ** NOTE: Primary landing runways 36L/R,18L/R. IAGOO NOTE:. DME/DME/IRU or GPS Required. ALBERT WHITTED NOTE: Turbojet/Turboprop aircraft only. NOTE: Radar Required. WOBKI NOTE: RNAV 1. KTPA Landing North: Expect radar vectors prior to WOBKI WP.

SEMINOLE TRANSITION (SZW.FOOXX1):

From FOOXX WP via 137° track to DADPE WP, thence as depicted to WOBKI WP, then via 065° heading. Expect radar vectors.

LOST COMMUNICATIONS:

KTPA Landing North: Continue track to WOBKI WP, then turn left to intercept the Runway 36L final approach course, conduct approach.

KTPA Landing South: Continue track to FOOXX WP, then turn left direct to HUGMA WP, conduct RNAV (GPS) Rwy 18R approach.

NOTE: Chart not to scale.

SE-3, 03 JUL 2008 to 31 JUL 2008